

Which flashes do these X-Tenders fit?

Based on our own use and feedback from our customers:

The FX-1 fits the Nikon SB-24 & SB 28, the Canon 430 EZ & 199D, the Minolta 5200 & 5400, and the Pentax 5000AF. The measurement between the ears of an FX-1 is 1-9/16" .

The FX-1B fits the Nikon SB-80 & SB 80dx.

The FX-2 fits the Canon 540 EZ & 550 EX, the Nikon SB-25 & SB-26, and the Sigma EF 500. The measurement between the ears of an FX-2 is 1-3/4" .

The FX-3 Custom fit for the Canon 580EX

The FX-4 Custom fit for the Nikon SB 800 and SB600

The FX-5 Custom modified for the Canon 430EX

We are not recommending the use of a Flash X-tender on the Nikon SB-50 or the Canon 420.