

LiteDome xs Accessory Hardware / Adjustable Shoe Mount

Product Info

SKU: AC-B222SM

[Instructions](#)

The **Adjustable Shoe Mount Hard** allows you to connect your shoe-mount style flash to our LiteDome xs. Allows mounting to a camera bracket or a light stand.

Use with our Shoe Mount Multiclar (AC-BSWCP) for tilt capability when using a light stand.

